



## CABLES AND WIRES

### **OBJECTIVE/GOAL:**

To provide homeowners with guidelines for the installation of cables and wires for telecommunication equipment to make them as inconspicuous as possible on the exterior of the home.

### **GUIDELINE DETAILS:**

- Any cable or wire should be installed so they are secured to the house structure and are concealed.
- Cables and wires may be concealed behind downspouts or along corner or trim boards. If it is necessary for any of the cables or wires to be visible, then they should be painted the color of the surface they cross unless this surface is brick.

---

No application is required to be submitted for any telecommunication equipment however all wires and cables must be installed in a professional manner and must be concealed as much as possible. Cables and wires should not pose any safety issue to either the resident or any adjoining property.

---

**Questions: Call Architectural Standards (301) 948-0110**

---